


Условное обозначение:

A4	One-touch shift
A4	One-touch shift
A4	One-touch shift
A4x1	Connector of operating unit A4 (10-pin)
A4x2	Connector of operating unitA4 (22-pin)
E14	Left reversing lamp
E15	Right reversing lamp
F24	Auxiliary fuse no. 24, circuit 15
F25	Auxiliary fuse no. 25, circuit 30
G4	Shift stage lock
J1	Circuit 30 connector sleeve
J21	Circuit 81a connector sleeve
J5	Circuit 50 connector sleeve
J57	Connector sleeve, kickdown switch
M1	Starter
M9	Range selection actuator motor
N2	ELR control module
N3	Kickdown control module
S2	Starter lockout switch
S3	Kickdown switch
X1	Frame/engine connector
X2	Terminal block 6-pin
X3	Plug connection at actuator motor M9 (4-pin)
X4	Connector on actuator motorM9 (8-pin)
X5	Plug connection (14-pin)
X6	Reversing lamp plug connection
Y2	Kickdown solenoid valve

Позиция:

4 A
12 A
20 A
1 C
8 C
13 L
15 L
2 H
3 H
5 L
4 L
12 E
8 H
21 H
6 L
18 L
25 L
24 A
10 L
23 L
6 H
3 L
19 H
15 H
9 H
13 H
22 L



Здесь приклеить страницу 2 ▼

