


Telephone:
Fax:
VAT Registration No.:

Y160	3rd piston cut-off solenoid
A63	AC control module
B138	Accelerator pedal position (APP) sensor
A137	Airbag control module
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S162	Cruise control actuator switch
X80	Data bus connection
X1	Data link connector (DLC)
R94	Engine breather heater
A35	Engine control module (ECM)
K46	Engine control relay
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B86	Engine oil level sensor
B156	Engine oil temperature sensor
Y28	Exhaust gas recirculation (EGR) solenoid
Y161	Exhaust gas recirculation (EGR) throttle control valve
Y63	Fuel pressure control solenoid
B26	Fuel pressure sensor
Y12	Fuel shut-off solenoid
B31	Fuel temperature sensor
F	Fuse
R5	Glow plug
A104	Glow plug control module
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
W3	Spare cable
M1	Starter motor
K4	Starter motor relay
S249	Transmission range (TR) sensor
Y68	Turbocharger (TC) wastegate regulating valve



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

